

USER MANUAL

SkinVibe Aurea Family x Plasma Hair Dryer



Read more at:

www.skinvibe.global



English Version

THANK YOU

We are very pleased, that you decided to choose SkinVibe!

Our priority is your satisfaction, so we make sure, to provide you with the high - quality products.

Please read the attached user manual carefully, it contains important informations regarding the proper use of our products.

Best regards,
SkinVibe Team

TABLE OF CONTENTS

Introduction	14
Contents of the box	15
Features	15
LED indicators.....	15
Product description	16
Button description	16
How to use	17
Cleaning the air filter	20
Styling nozzles	21
Safety precautions	22
Technical specifications	22
Warranty	23
Contact information	24
Certificates	25
Manuals in other languages	26

CONTENTS OF THE BOX

- SkinVibe Aurea Family x Plasma Hair Dryer
- Three magnetic styling nozzles
- User manual
- Bag for the device
- Thank you card

FEATURES


- Prevents static electricity by generating 1 billion positive and negative ions.
- Equipped with a grip sensor function, making it automatic to turn on and off during use.
- Provides quiet but powerful wind with a 110,000rpm high-performance BLDC motor.
- Customized care according to the situation in 7 modes.
- Safe use with warning light display in case of overheating or low voltage problems.
- Detachable magnetic air filter cover makes dust removal easy.
- 2-level wind speed and 4-level wind temperature control.
- Included magnetic nozzles make it easy to model hair.
- Easy-to-view operation with LCD screen.
- Easy button operation.
- Thick wire that is not easily twisted or prone to peeling even with physical shock.

LED INDICATORS

During drying, the round frame of the screen lights up in 4 different colors, depending on the selected temperature:

- **Hot air:** red LED
- **Warm air:** orange LED
- **Gentle air:** yellow LED
- **Cold air:** blue LED


PRODUCT DESCRIPTION



- 1 Air vent
- 2 LCD screen
- 3 Temperature indication ring
- 4 Mode change button
- 5 Power and wind speed control button

- 6 Wind temperature control button
- 7 Body with touch sensor
- 8 Air filter
- 9 Power plug

BUTTON DESCRIPTION



- 1. **Mode change button:** Press the mode button to select the desired mode and long press to set the language.
- 2. **Power and wind speed control button:** Slide up and down to turn power ON/OFF and adjust wind speed.
- 3. **Wind temperature control button:** Change the wind temperature by pressing the button and press long to turn touch sensor ON/OFF.




HOW TO USE




1. Power ON/OFF




- After washing hair, dry with a towel.
- Plug in the dryer and start use.
- Turn on the power and adjust the desired wind speed level with the slide button.



2. Change wind temperature and mode

- Change Wind Temperature: Press the Wind temperature control button to change the temperature.
- Change Mode: Press the Change Mode button to use the desired mode.

Mode	DESCRIPTION
 The control panel for Isothermal Mode features a circular design. At the top, it says 'Isothermal Mode'. Below this is a temperature gauge with a thermometer icon and a 'Touch sensor' label. To the right is a 'Plasma' button with a plus sign. At the bottom, there is a 'Low-Speed' button with a fan icon.	Quickly dries hair while maintaining a constant, selected air temperature, with a maximum speed of 110,000 RPM (92,000 in low-speed mode). • Choose desired wind temperature from warm, hot or cold air. ◦ Warm air: 55°C ± 5°C ◦ Hot air: 80°C ± 5°C ◦ Cold air: room temperature • Equipped with a smart memory function, allowing it to start at the last set wind temperature even after being turned off and on.
 The control panel for Alternating Warm & Cold Mode features a circular design. At the top, it says 'Alternating Warm & Cold Mode'. Below this is a temperature gauge with a sun and snowflake icon and a 'Touch sensor' label. To the right is a 'Plasma' button with a plus sign. At the bottom, there is a 'High-Speed' button with a fan icon.	Apply warm and then cold air to set the style. • Warm air 3 seconds ⇄ Cold air 4 seconds: The air temperature switches automatically.
 The control panel for Alternating Hot & Cold Mode features a circular design. At the top, it says 'Alternating Hot & Cold Mode'. Below this is a temperature gauge with a sun and snowflake icon and a 'Touch sensor' label. To the right is a 'Plasma' button with a plus sign. At the bottom, there is a 'High-Speed' button with a fan icon.	Apply hot and then cold air to set the style. • Hot air 3 seconds ⇄ Cold air 4 seconds: The air temperature switches automatically.

Mode	DESCRIPTION
	When drying long hair, use the appropriate temperature and time to minimize hair damage. Operation sequence: 1 minute of hot air → 3 minutes in Alternating Hot & Cold Mode → 2 minutes of warm air → 1 minute of cold air → Alternating Hot & Cold Mode • After operating in sequence, remains in the last Alternating Hot & Cold Mode.
	When drying short hair, use the appropriate temperature and time to minimize hair damage. Operation sequence: 1 minute of hot air → 1 minute in Alternating Hot & Cold Mode → 1 minute of warm air → 1 minute of cold air → Alternating Hot & Cold Mode • After operating in sequence, remains in the last Alternating Hot & Cold Mode.
	The wind blows at a lower wind speed and temperature than the normal mode, making it suitable for children, pets, or styling. The rotation speed is lowered from a maximum of 80,000 RPM to a minimum of 65,000 RPM. • Choose the desired wind temperature among warm, hot or cold air. ◦ Warm air: $55^{\circ}\text{C} \pm 5^{\circ}\text{C}$ ◦ Hot air: $65^{\circ}\text{C} \pm 5^{\circ}\text{C}$ ◦ Cold air: $38 \pm 5^{\circ}\text{C}$ • Equipped with a smart memory function, allowing it to start at the last set wind temperature even after being turned off and on.

Mode	DESCRIPTION
	Provides airflow at low speed and temperature, making it ideal for drying the fur and skin of animals with various coat types, which have a higher skin temperature than humans. It operates quietly with a rotation speed of 65,000 to 75,000 RPM. - Choose the desired air temperature from: warm, gentle, or cool air. Warm air: $45^{\circ}\text{C} \pm 5^{\circ}\text{C}$ Gentle air: $35^{\circ}\text{C} \pm 5^{\circ}\text{C}$ Cool air: room temperature - Equipped with a smart memory function, allowing it to start at the last set wind temperature even after being turned off and on.
	Use the product more conveniently and smartly by activating the touch sensor. - Press and hold the wind temperature button for about 3 seconds to turn ON/OFF the touch sensor. - The product starts to operate when touching the main body with hand while on, When removing hand from the main body, the operation automatically stops.
	This warning appears as low voltage when the plug contact is poor. Indicator: Orange LED Solution: Ensure the plug is securely inserted and plug it in again.
	This warning appears when the NTC (temperature monitoring sensor) is broken in the product. Indicator: Blue LED Solution: Please contact customer service.


Mode	DESCRIPTION
 Error 3 Over Temperature	This warning appears when the product is overheated. • Indicator : Red LED • Solution: Clean the air vent and air filter.
 Language settings Polish English	Hold down the mode change button for 3 seconds to enter the language setting screen. Press the mode change button to select the desired language, then hold again for 3 seconds to confirm the settings. • If no action is performed on the language setting screen, the language will be automatically set after about 10 seconds.
	A flashing plasma icon on the screen indicates that the plasma function operates continuously throughout the entire use of the device.

CLEAN THE AIR FILTER

We recommend regularly cleaning the air filter to remove accumulated dust, ensuring proper operation of the device.




1. Turn off the hair dryer and unplug it from the power source.
2. Gently pull the filter downward to remove it.
3. Wipe off the dust with a soft cloth, tissue, brush, or dry cloth.
4. Insert the filter back upward.

Do not wash with water. This may cause device malfunction.



STYLING NOZZLES

Your hair dryer is equipped with magnetic styling nozzles that can be easily mounted and rotated in any direction to precisely adjust the airflow. To remove the nozzles, simply grasp their cool edges.

NOZZLE	DESCRIPTION
 Professional concentrator	Precision styling concentrator, perfect for accurately shaping specific sections of hair. Provides a controlled airflow, making it easier to create detailed hairstyles.
 Basic concentrator	Wide concentrator for everyday hair drying, providing even airflow. Perfect for fast drying and smoothing the entire surface of the hair.
 Diffuser	Large, wide, round and wavy cap with teeth inside. Evenly distributes air to create defined curls and minimize frizz.

SAFETY PRECAUTIONS

- Do not leave the hair dryer plugged into the socket unattended.
- Do not wrap the cord around the product body.
- Do not put your hand into the air vent – there is a risk of burns.
- Do not use the hair dryer if the air vent is blocked. It can cause a fire.
- Be careful not to let your hair get caught in the air vent.
- When cleaning the air filter, make sure the dryer is turned off, unplug the cord, and then clean the device.
- Do not use the hair dryer with wet hands or on wet hair to avoid electric shock.
- We recommend storing the dryer in a dry, indoor place, away from moisture and direct sunlight.
- Do not use the dryer for purposes other than drying and styling hair (e.g., drying shoes or clothes), as the housing may deform due to heat.
- Be cautious of the risk of electric shock and fire – avoid using or storing the device in places where it may fall.
- If the product is damaged or not functioning properly, do not disassemble or attempt to repair it yourself. Contact customer service.
- Do not use accessories other than those provided by the manufacturer.
- Keep out of reach of children, unless they are supervised or instructed by a responsible person to ensure safe use.
- Do not use the product near bathtubs, showers, sinks, or other containers filled with water.
- When using the negative ion function, a specific smell may occur, which is not harmful to health.
- If the power cord or plug is damaged, stop using the device immediately and contact customer service.

TECHNICAL SPECIFICATIONS

- Model: SV-001SL, SV-005MM
- Rated voltage: 230V ~ 50-60Hz
- Cord length: 2.7m
- Power consumption: 1600W
- Display: LCD
- Motor speed: 110,000 RPM

Made in PRC

Keep this manual for future reference.

WARRANTY

The warrantor is: ITRG-ZIĘBA-MAGIERA-STYLIŃSKI SPÓŁKA JAWNA, VAT NO: PL9452174051, Christo Botewa 6B/B4, 30-798 Cracow, Poland.

The warranty covers the product: SkinVibe Aurea Family x Plasma Hair Dryer.

Congratulations on your purchase.

This product is covered by a 24-month warranty from the date of purchase. Warranty service is provided based on proof of purchase (receipt or VAT invoice).

In the event of a defect, the Buyer should contact the Authorized Service Center at the following address: Christo Botewa 6B/B4, 30-798 Cracow, Poland. You can reach us through the following contact options:

- By email:
 - handel@itrg.pl
 - RMA@itrg.pl

The Warrantor collects the product from the Buyer at its own cost. Repair costs or product replacement costs, including shipping, labor, and materials, are covered by the Warrantor.

In the case of a justified claim, the Warrantor commits to repairing or replacing the faulty product free of charge within 30 days of receiving the complaint. If the Warrantor fails to respond to the claim within this period, the Buyer has the right to request a product replacement or refund.

The warranty does not cover risks related to damage or wear to the product during shipment to the Authorized Service Center unless this transport is organized by the Warrantor.

The warranty does not cover:

- a) normal wear and tear;
- b) periodic technical inspections;
- c) damage and failures caused by improper or non-compliant use with the user manual, or handling of the Product in a manner inconsistent with normal applications;
- d) damage resulting from use of the Product contrary to its intended purpose, including:
 - physical, aesthetic, or surface damage caused by improper use or modifications;
 - improper installation or use of the Product not in accordance with the instructions;
 - lack of servicing in accordance with the manufacturer's recommendations;
 - installation not compliant with the user manual and applicable safety standards;
 - use of the Product with non-recommended accessories or peripheral devices;
 - repairs carried out by unauthorized persons;
 - modifications of the Product without the consent of the importer or Authorized Service Center, such as:
 - increasing the parameters of the Product beyond the values specified in the manual;

- adapting the Product to local technical standards in countries other than those for which it was designed;
- negligence.

e) accidents, fire, contact with liquids or moisture, chemicals and other substances, flooding, vibrations, excessive heat, inadequate ventilation, connection to excessive or incorrect voltage, radiation, electrical discharges including lightning, as well as the action of any external forces and impacts.

The warranty applies within the territory of the European Union.

If the product does not conform to the sales contract, the Buyer is entitled to rights under applicable consumer protection laws in addition to the rights granted under this warranty.

CONTACT INFORMATION

Contact: handel@itrg.pl

Service: RMA@itrg.pl

Contact: contact@skinvibe.global

Importer and distributor:

ITRG-ZIĘBA-MAGIERA-STYLIŃSKI SPÓŁKA JAWNA
Christo Botewa 6B/B4
30-798 Cracow, Poland
VAT NO: PL9452174051

Manufacturer:

VISIONARY GROUP SP. Z O.O.
Skwierzyńska 2
04-853 Warsaw, Poland
VAT NO: PL9522268798

CERTIFICATES



Environmental Protection Instructions

Note: This device is marked in accordance with the European Directive 2002/96/EC and the Polish Act on Waste Electrical and Electronic Equipment with the symbol of a crossed-out waste container.

This marking indicates that this equipment, after its period of use, cannot be disposed of together with other household waste.

Warning: do not dispose of this equipment with municipal waste!!!

The product must be disposed of through selective collection at designated collection points.

Proper handling of waste electrical and electronic equipment helps to avoid harmful effects on human health and the environment due to the presence of hazardous substances and improper storage and processing of such equipment.



Child Safety Warning

Note: This product is not intended for children under 3 years of age.

The crossed-out baby face symbol indicates that the device may pose a choking hazard or other risk if used by small children.

Keep out of reach of children.



Water and Electrical Device Warning

Note: This is an electrical device – do not immerse it in water or use it near liquids (e.g., during bathing).

The crossed-out bathtub symbol indicates that the device must not be used in the bath, under the shower, or near any water-filled container.

Use extra caution when operating in bathrooms.

EU DECLARATION OF CONFORMITY (No. SV-001/2025/CE/1)



Product: SkinVibe Aurea Family x Plasma Hair Dryer (model no. SV-001SL, SV-001MM)


Manufacturer:

Visionary Group Sp. z o.o.
VAT NO: PL9522268798
Skwierzyńska 2
04-853 Warsaw, Poland

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The product listed above is in conformity with the Electromagnetic Compatibility Directive 2014/30/EU. The following standards have been applied:

- EN 55032:2015/AC:2016
- EN 61000-3-2:2014
- EN 61000-3-3:2013
- EN 55024:2010+A1:2015



MANUALS IN OTHER LANGUAGES

Full product manuals in other languages are available online.

Visit our website:

www.skinvibe.global/pages/manuals

or scan the QR code below:

