


USER MANUAL

Wireless hair straightener SkinVibe Luna MiniWireless



Learn more at:

www.skinvibe.global



English version

THANK YOU

We are very pleased, that you decided to choose SkinVibe!

Our priority is your satisfaction, so we make sure, to provide you with the high - quality products.

Please read the attached user manual carefully, it contains important informations regarding the proper use of our products.

Best regards,
SkinVibe Team

TABLE OF CONTENTS

Introduction	12
Box contents	13
Safety instructions	13
Device structure	14
Battery charging	14
Device operation	15
Cleaning and maintenance	17
Device disposal	17
Technical specifications	17
Warranty	18
Contact information	19
Certificates	20
Manuals in other languages	21

BOX CONTENTS


- Wireless hair straightener SkinVibe Luna MiniWireless
- USB-C cable
- Charging station
- User manual
- Bag for the device
- Thank you card

SAFETY INSTRUCTIONS

These warnings apply to the device as well as all tools, accessories, charging station, USB cable, and power cord.

- This device is not intended for use by children.
- Always use the device with the provided USB charging cable. If the power cord is damaged, it must be replaced by a service center to avoid hazards.
- The device is not waterproof. Do not use it near water. Water poses a danger even when the device is turned off.
- Do not insert any foreign objects into any openings of the device.
- If the device is malfunctioning, has been dropped, damaged, or left exposed to external elements or submerged in water, do not use it and contact customer service.
- The heating plates of the device can remain hot during use. Allow them to cool down after use. Handle the device carefully, especially in the presence of small children.
- Do not leave the device turned on when not in use.
- Do not use the device until it is fully charged.
- The battery in the device is non-replaceable. If the device does not function properly or the battery is damaged, do not attempt to replace it yourself. Contact customer service.
- Do not expose the device to high temperatures, as this may cause battery failure.
- Skin contact with the device may cause irritation. In case of skin contact, wash with soap and water.
- Eye contact may cause irritation. In case of contact, immediately rinse your eyes and seek medical attention.
- Use the device only for styling dry scalp hair. Do not use on wet or damp hair.
- It is prohibited to use the device while it is charging. Do not use the device when plugged into electrical outlets.
- If the device falls into a liquid while charging, immediately disconnect the power plug and the charging cable from the outlet.
- If the device is not used for a period of 6 months, the battery will lose its full capacity.
- If the product has not been used for at least 14 days, turn it on, fully discharge the battery, and then recharge it to full capacity. Repeat this process every 14 days if the device is not in continuous use.

DEVICE STRUCTURE



BATTERY CHARGING

Charging via USB-C cable

The device is powered wirelessly by a built-in battery, which needs to be charged regularly.

Follow these steps to charge the battery:

1. **Turn off:** Ensure the device is turned off.
2. **Connect:** Plug the USB-C cable into the port on the back of the device.
3. **Charging time:** Charging takes approximately 4 hours. The battery icon on the display shows the battery charge level.
4. **Ready for use:** A fully charged battery is indicated on the display. Your device is now ready for use.

DEVICE OPERATION

Before use:

1. **Turn off flight mode:** move the button up.
2. **Brush your hair:** Make sure your hair is brushed and arranged in the desired style direction.
3. **Lightly dampen your hair:** Lightly and evenly dampen your hair with styling products, water, or a towel.
 - Overly wet hair will not style well, so ensure it is only slightly damp.



Tips for achieving the best styling results:

- Brush your hair with a comb.
- Divide your hair into sections as shown in the illustration.
 - If you have thick hair, dividing it into smaller sections will make styling easier.
- Start styling at the back of your head, beginning with sections **1** and **2**, and then moving to sections **3** and **4**.




Hair Straightening:

1. Grab a section of hair about 5 cm wide. Do not take too much hair at once, as this may make straightening difficult.
2. Place the section of hair between the device's plates and clamp it near the roots.
3. Slowly slide the straightener from the roots to the ends, adjusting the pressure for the best effect.
4. Repeat steps 1–3 for the rest of your hair. Start from the lower sections and work your way up to the next sections.



Curling the Ends (for tight curls):

1. Take a section of hair about 5 cm wide. Ensure that the section of hair is placed between the straightener's plates.
2. Clamp the straightener at the ends of the hair so the plates touch the hair, then gently wrap the hair around the straightener.



3. Twist the straightener inward, so the plates face the scalp, and the hair ends are pointing away from you.



4. Hold the straightener in place for about 7 seconds. If the curls do not hold, repeat this step.
 - Note: Do not hold the straightener in one spot for more than 10 seconds to avoid damaging the hair.

5. Repeat steps 1–4 for the remaining sections of hair.



CLEANING AND MAINTENANCE

Take care of the device's cleanliness after each use. Before starting the cleaning process, turn off the device and wait until the heating plates have completely cooled down.

- Do not immerse the device in water or any other liquids.
- Wipe the device with a dry or slightly damp cloth.
- Do not use any corrosive substances such as alcohol or strong detergents to clean the device.
- Handle the device gently.

DEVICE DISPOSAL

The device contains a battery. Do not attempt to disassemble the battery from the device yourself.

The device should be disposed of at a facility specializing in the disposal of electrical equipment. Disposal should be carried out in accordance with local regulations regarding waste disposal.

TECHNICAL SPECIFICATIONS

- Model: SV-003BK, SV-003WH
- Display: LCD
- Power: 22W
- Input Voltage: DC 5V-2A
- Temperature Range: 165°C, 185°C, 210°C
- Lithium-ion battery capacity: 4000mAh
- Charging: USB-C cable (included)
- Operating time: 50 minutes
- Charging time: 4 hours

Made in PRC

Keep this manual for future reference.

WARRANTY

The warrantor is: ITRG-ZIĘBA-MAGIERA-STYLIŃSKI SPÓŁKA JAWNA, VAT NO: PL9452174051, Christo Botewa 6B/B4, 30-798 Cracow, Poland.

The warranty covers the product: Wireless hair straightener SkinVibe Luna MiniWireless.

Congratulations on your purchase.

This product is covered by a 24-month warranty from the date of purchase. Warranty service is provided based on proof of purchase (receipt or VAT invoice).

In the event of a defect, the Buyer should contact the Authorized Service Center at the following address: Christo Botewa 6B/B4, 30-798 Cracow, Poland. You can reach us through the following contact options:

- By email:
 - handel@itrg.pl
 - RMA@itrg.pl

The Warrantor collects the product from the Buyer at its own cost. Repair costs or product replacement costs, including shipping, labor, and materials, are covered by the Warrantor.

In the case of a justified claim, the Warrantor commits to repairing or replacing the faulty product free of charge within 30 days of receiving the complaint. If the Warrantor fails to respond to the claim within this period, the Buyer has the right to request a product replacement or refund.

The warranty does not cover risks related to damage or wear to the product during shipment to the Authorized Service Center unless this transport is organized by the Warrantor.

The warranty does not cover:

- a) normal wear and tear;
- b) periodic technical inspections;
- c) damage and failures caused by improper or non-compliant use with the user manual, or handling of the Product in a manner inconsistent with normal applications;
- d) damage resulting from use of the Product contrary to its intended purpose, including:
 - physical, aesthetic, or surface damage caused by improper use or modifications;
 - improper installation or use of the Product not in accordance with the instructions;
 - lack of servicing in accordance with the manufacturer's recommendations;
 - installation not compliant with the user manual and applicable safety standards;
 - use of the Product with non-recommended accessories or peripheral devices;
 - repairs carried out by unauthorized persons;
 - modifications of the Product without the consent of the importer or Authorized Service Center, such as:
 - increasing the parameters of the Product beyond the values specified in the manual;

- adapting the Product to local technical standards in countries other than those for which it was designed;
- negligence.

e) accidents, fire, contact with liquids or moisture, chemicals and other substances, flooding, vibrations, excessive heat, inadequate ventilation, connection to excessive or incorrect voltage, radiation, electrical discharges including lightning, as well as the action of any external forces and impacts.

The warranty applies within the territory of the European Union.

If the product does not conform to the sales contract, the Buyer is entitled to rights under applicable consumer protection laws in addition to the rights granted under this warranty.

CONTACT INFORMATION

Contact: handel@itrq.pl

Service: RMA@itrq.pl

Contact: contact@skinvibe.global

Importer and distributor:

ITRG-ZIĘBA-MAGIERA-STYLIŃSKI SPÓŁKA JAWNA
Christo Botewa 6B/B4
30-798 Cracow, Poland
VAT NO: PL9452174051

Manufacturer:

VISIONARY GROUP SP. Z O.O.
Skwierzyńska 2
04-853 Warsaw, Poland
VAT NO: PL9522268798

CERTIFICATES



Environmental Protection Instructions

Note: This device is marked in accordance with the European Directive 2002/96/EC and the Polish Act on Waste Electrical and Electronic Equipment with the symbol of a crossed-out waste container.

This marking indicates that this equipment, after its period of use, cannot be disposed of together with other household waste.

Warning: do not dispose of this equipment with municipal waste!!!

The product must be disposed of through selective collection at designated collection points.

Proper handling of waste electrical and electronic equipment helps to avoid harmful effects on human health and the environment due to the presence of hazardous substances and improper storage and processing of such equipment.



Child Safety Warning

Note: This product is not intended for children under 3 years of age.

The crossed-out baby face symbol indicates that the device may pose a choking hazard or other risk if used by small children.

Keep out of reach of children.



Water and Electrical Device Warning

Note: This is an electrical device – do not immerse it in water or use it near liquids (e.g., during bathing).

The crossed-out bathtub symbol indicates that the device must not be used in the bath, under the shower, or near any water-filled container.

Use extra caution when operating in bathrooms.

EU DECLARATION OF CONFORMITY (No. SV-003/2025/CE/1)



Product: Wireless hair straightener SkinVibe Luna MiniWireless (model no. SV-003BK, SV-003WH)


Manufacturer:

Visionary Group Sp. z o.o.
VAT NO: PL9522268798
Skwierzyńska 2
04-853 Warsaw, Poland

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The product listed above is in conformity with the Electromagnetic Compatibility Directive 2014/30/EU. The following standards have been applied:

- EN 55032:2015/AC:2016
- EN 61000-3-2:2014
- EN 61000-3-3:2013
- EN 55024:2010+A1:2015



MANUALS IN OTHER LANGUAGES

Full product manuals in other languages are available online.

Visit our website:

www.skinvibe.global/pages/manuals

or scan the QR code below:

